

FOREVER WATERSLIDE

Laser transfer paper for glass, candles, ceramic, metal and wood.

PRINT SETTINGS

Paper Weight · 140-170gsm

Image Mode · No Mirror

Feed Mode · Multi-Purpose Tray (Bypass/Manual Feed)

APPLICATION

1. Print your image/design onto the glossy side of FOREVER Waterslide.
2. Contour cut (or trim with scissors) your design.
3. Soak the transfer paper in a bowl of water for 30 seconds.
4. Remove backing paper from FOREVER Waterslide.
5. Position the transfer and brush lightly with your fingers or a piece of flexible plastic to remove any trapped air.
6. Carefully dab away all excess water using a small sponge or piece of cloth.
7. Allow to dry for a minimum of 3 hours.

This transfer paper is suitable only for Laser Printers.

Are you experiencing problems with this transfer paper?

Don't panic, it does work.

Call us on 01244 541 647 or E-Mail info@forevertransferpaper.com